



PLEASE NOTE:

For optimum performance & to prevent the potential for dry-fire or mis-fire, please follow these guidelines:

1. Always maintain 10 to 12 pounds down pressure
2. Keep driver level on the post at all times
3. Do not allow the barrel to contact the ground
4. Do not push throttle trigger unless on a post



Optional handle extension kit available. Adds 2 1/2' to your handles!

- In the event of dry-fire or mis-fire you will need to re-engage your hammer by lifting the driver up and setting it back down on the post with some pressure applied
- Continual dry-fire or mis-fire will cause the barrel to come out, or bottom bolts to shear off, this is not covered under warranty
- Your driver will arrive with the engine oil filled, do not add any oil until necessary
- Your driver will arrive with grease in the crank, do not add any grease. It is only necessary to check the crank grease every 3 or 4 months

If you have a Boss Model you may have a big black rubber band, this goes around your barrel bolts to help secure them, fold up to double the layer for longer life of the band

Questions? Call (509) 235-2780